



MAIN MENU

DEFAULT VALUES ARE DISPLAYED IN BOXES



SECONDARY MENUS

PRESS MENU ICON (LCD) OR MENU BUTTON TO ACCESS



RED EPIC
EPIC-M & EPIC-X

TITLE:

MENU MAP

VERSION: 3.0

©2011-12 RED.COM, INC.

REV

SHEET 1 OF 4


A

SECONDARY MENU

PRESS MENU ICON (LCD) OR MENU BUTTON TO ACCESS

FLOWCHART CONCEPT XL FILMS LTD.

DEFAULT VALUES ARE DISPLAYED IN BOXES



RED EPIC
EPIC-M & EPIC-X

TITLE:

MENU MAP

VERSION: 3.0

©2011-12 RED.COM, INC.



REV
A

SHEET 2 OF 4

SECONDARY MENU

PRESS MENU ICON (LCD) OR MENU BUTTON TO ACCESS

DEFAULT VALUES ARE DISPLAYED IN BOXES



ALLOWS PLAYBACK OF CLIPS ON ATTACHED MEDIA
 - CAN ALSO BE ACCESSED BY SELECTING THE ARROW IN THE UPPER LEFT CORNER OF THE LCD SCREEN
 - TO EXIT PLAYBACK, SELECT THE CIRCLE IN THE UPPER LEFT CORNER
 REFER TO OPERATION GUIDE FOR OPERATIONAL DETAILS AND FEATURES

SERIAL PROTOCOL
 NONE
 ELEMENT TECHNICA
 3ALITY SPC 7100
 3ALITY SPC 7000
 None

CAMERA IN
 SYNC IN
 GENERAL PURPOSE IN
 Sync In

CAMERA OUT
 SYNC OUT
 GENERAL PURPOSE OUT
 Sync Out

SYNC MODE
 OFF SHUTTER PROXY
 GENLOCK INTERNAL SLAVE
 Off

FAN CONTROL
 MANUAL / AUTO
 Auto

REC SPEED
 25 TO 100%
 50%

STBY SPEED
 25 TO 100%
 75%

BEEP SPEAKER
 OFF RECORD / STOP
 Off

EVF TALLY LIGHT

SYS STATUS
 DISPLAYS SYSTEM CONFIGURATION SCREEN

SYS INFO
 DISPLAYS CAMERA PIN & SOFTWARE VERSION

SAVE LOG
 SAVES SYSTEM LOG FILE TO EXTERNAL MEDIA

SW UPDATE
 CHECKS EXTERNAL MEDIA FOR SOFTWARE UPDATE
 PROMPTS FOR INSTALL

CALIBRATION

SELF TEST

RESTORE SYS
 PROMPTS TO RESTORE TO FACTORY SETTINGS
 REQUIRES REBOOT OF CAMERA

REDISCOVER
 REDISCOVERS ALL HARDWARE
 REQUIRES REBOOT OF CAMERA

CUR. CAL MAP
 FACTORY USER HS
 Factory

BLACK SHADING (DEFAULT)
 PROMPTS TO PERFORM BLACK SHADING CALIBRATION

BLACK SHADING (CURRENT FPS/EXPOSURE)
 PROMPTS TO PERFORM BLACK SHADING CALIBRATION

KEY SOURCE
 Refer to Operation Guide

USER KEY
 Refer to Operation Guide

KEY ACTION
 Refer to Operation Guide

MENU KEY RETURNS TO SETTINGS MENU

SENSOR TEST PATTERN
 ENABLE / DISABLE SENSOR TEST PATTERN

TOUCHSCREEN
 ENABLES TOUCHSCREEN TEST TO EXIT, TAP AND HOLD OR PRESS ENTER BUTTON