



SENSOR MENU BUTTON


DEFAULT VALUES ARE DISPLAYED IN WHITE



VIDEO MENU BUTTON



DEFAULT VALUES ARE DISPLAYED IN WHITE



DEFAULT VALUES ARE DISPLAYED IN WHITE

